



PROCESSING INSTRUCTIONS

KAMBA BATH

Your anti-slip coating for bathrooms and bathtubs

Item number 16200 / 16250

Important note:

During coating and for 24 hours afterwards, ensure that the surface temperature is above 15°C!

Before use, observe the safety instructions on the respective labels!

In our safety box, you will find everything you need for YOUR SLIP RESISTANCE in accordance with DIN 51097:

For steps 1+2, we recommend that you wear household gloves

1. Removal of all limescale residues:
Wet the surface with warm water.
Apply KAMBA limescale remover evenly, leave to work for a short time (approx. 5-10 minutes), Repeat the process if necessary.
2. Removal of all dirt and soap residues:
Apply KAMBA special cleaner to the moistened surface and clean with a sponge/brush. Rinse with cold water.
Rub the surface dry and keep it completely dry.
Pro tip: Place a plastic bag over the shower head and faucet – don't forget the overhead shower (risk of dripping).
3. Limit the area to be coated with the enclosed adhesive tape.
4. Place the special roller on the roller bracket
5. KAMBA Bath - Shake vigorously (>2 min.) The quantity is sufficient for approx. 2 m².
6. Pour the required amount into the enclosed coating tray.
7. Dip the special roller into the coating material; roll out any excess material until the roller is evenly saturated and no longer drips.

8. Begin coating. Always work from the center of the surface outwards. First coat the surface evenly and thinly in one direction then, at a 90° angle, spread the already applied material again with the roller; again at a 90° angle (without applying pressure to the roller) roll the surface.
9. Please remove the adhesive tape immediately after coating.
10. Any unused anti-slip coating material can be poured back into the bottle. The bottle is tightly sealed and can be stored at cellar temperature for approx. 3 months.
11. Wash all tools thoroughly with lukewarm water for reuse.
12. After 12 hours of drying time, your shower/bathtub is ready for use again.
(Optimal conditions: temperature > 20°C and good ventilation!)
13. Mechanical cleaning may only be carried out after one week of drying

We are happy to assist you with any problems. Simply send an email to info@kamba-antirutsch.de